



Package Contents



UBB (Qty. 2)



Ball Joint Mount (Qty. 2)



Lock Ring (Qty. 2)



Metal Strap (Qty. 2)



Gigabit PoE (48V, 0.32A) with Mounting Bracket (Qty. 2)



Power Cord (Qty. 2)

System Requirements


- One of the following:
 - UniFi Cloud Key (1.0.5 or newer) or UniFi Dream Machine (1.0.1 or newer)
 - Linux, Mac OS X, or Microsoft Windows 7/8/10
 - Java Runtime Environment 1.6 (1.8 or newer recommended)
 - UniFi Controller software v5.12.x (or newer), available at: ui.com/download/unifi
- UniFi Network App (iOS or Android™) or Web Browser (Google Chrome preferred)

Installation Requirements


- Pole-mounting: 8 mm socket wrench or screwdriver
- Wall-mounting: wall fastener (not included)
- The device needs to have clear line of sight to the sky for proper GPS operation.
- Shielded Category 5 (or above) cabling with drain wire should be used for all wired Ethernet connections and should be grounded through the AC ground of the PoE.
We recommend that you protect your networks from harmful outdoor environments and destructive ESD events with industrial-grade, shielded Ethernet cable from

UBB Quick Start Guide

- Surge protection should be used for all outdoor installations. We recommend that you use two Ethernet Surge Protectors, model ETH-SP-G2, one near the device and the other at the entry point to the building. The ETH-SP-G2 will absorb power surges and safely discharge them into the ground.




Hardware Overview





UBB Quick Start Guide




1 System LED	
Flashing White	Initializing.
White	Factory defaults, waiting for integration.
Alternating White/Blue	Device is busy; do not touch or unplug it. This usually indicates that a process such as a firmware upgrade is taking place.
Blue	Successfully integrated into a network and working properly.
Flashing	This is used to locate a device. When you click Locate in the UniFi Network Controller software, the LED will flash blue. The software will also display the location of the device on the map.
2 Reset Button	
Resets to factory defaults. The device should be running after bootup is complete. Press and hold the Reset button for about 10 seconds until the LED starts flashing and then becomes solidly lit. After a few seconds, the LED will turn off, and the device will automatically reboot.	
	Note: The UBB radios are pre-paired. If a link is lost due to configuration changes, you can reset both UBB radios to re-establish the link.
3 Ethernet Port	
Local UBB radio (source LAN) This Gigabit Ethernet port is used to connect the power and should be connected to the LAN and DHCP server.	



DHCP server via the wireless link to the local UBB radio.

UBB Quick Start Guide






For each UBB radio, go to the appropriate mounting instructions: Pole Mounting or ["Wall Mounting"](#).

Pole-Mounting


1.




2.



3.



4.




Wall Mounting

The device must be mounted directly to a wood stud or other structurally stable surface to avoid damage to the mounting hole when you adjust the aim.

Optional Accessory

To enhance stability, you can use the NanoBeam® Wall Mount Kit, model NBE-WMK (sold separately).




Note: Center screw included. Two optional screws (not included) provide additional stability.

Installation Instructions

- 1.



UBB Quick Start Guide




2.



3.




UBB Quick Start Guide



Fastener (not included)



NanoBeam Wall Mount Kit




Aiming

Visually aim the UBB radios at each other:


1.



UBB Quick Start Guide



2.



Connecting Power

For each UBB radio:

1.



UBB Quick Start Guide




2.




3.



4.  **WARNING:** The switch port must comply with the power specifications listed in the Specifications section of this Quick Start Guide.




OR



Optional

UBB Quick Start Guide



Adopting the UBB

The UBB radios are pre-paired. For each UBB radio, you have the following options:

- [“Using the UniFi Network App”](#)
- [“Using the UniFi Network Software”](#)



Note: If a link is lost due to configuration changes, you can reset both UBB radios to re-establish the link.


Using the UniFi Network App

1.



2.

UBB Quick Start Guide




3.



4.




UBB Quick Start Guide



5. The System LED will turn blue to confirm that it has been successfully adopted.


Using the UniFi Network Software

1. From the UniFi Network Controller dashboard, click Devices in the left menu bar.



2. On the Devices screen, locate the UBB in the list of devices under the Model column. To adopt the UBB, click Adopt.

UBB Quick Start Guide



3. The System LED will turn blue to confirm that it has been successfully adopted.

Specifications

UBB	
Dimensions	140 x 140 x 90 mm (5.51 x 5.51 x 3.54")
Weight	376 g (13.3 oz)
Antenna Gain	
2.4 GHz (BLE)	2 dBi
5 GHz	10 dBi
60 GHz	17.2 dBi
GPS	Yes
Networking Interface	10/100/1000 Ethernet Ports Bluetooth for Management
Enclosure	UV-Resistant Polycarbonate
Power Method	802.3af Supported Passive Power over Ethernet (48V)
Power Supply	UniFi PoE Switch 48V, 0.32A Gigabit PoE Adapter (Included)
Max. Power Consumption	11W
Wind Loading	56 N @ 200 km/h (12.6 lbf @ 125 mph)
Wind Survivability	200 km/h (125 mph)
Mounting	Pole-Mount (Kit Included) Wall-Mount (Not Included)
ESD/EMP Protection	± 24kV Contact/Air
Operating Temperature	-40 to 60° C (-40 to 140° F)
Operating Humidity	5 to 95% Noncondensing

UBB Quick Start Guide

Certifications		CE, FCC, IC
Operating Frequency (MHz)		
Worldwide		5150 - 5875 57,000 - 66,000
US/CA	U-NII-1:	5150 - 5250
	U-NII-2A	5250 - 5350
	U-NII-2C	5470 - 5725
	U-NII-3:	5725 - 5850
		57,000 - 67,000
Bluetooth (MHz)		
Worldwide		2400 - 2483.5

Safety Notices

1. Read, follow, and keep these instructions.
2. Heed all warnings.
3. Only use attachments/accessories specified by the manufacturer.



WARNING: Do not use this product in location that can be submerged by water.



WARNING: Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.

Electrical Safety Information

1. Compliance is required with respect to voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed.
2. There are no operator serviceable parts inside this equipment. Service should be provided only by a qualified service technician.
3. This equipment is provided with a detachable power cord which has an integral safety ground wire intended for connection to a grounded safety outlet.
 - a. Do not substitute the power cord with one that is not the provided approved type. Never use an adapter plug to connect to a 2-wire outlet as this will defeat the continuity of the grounding wire.
 - b. The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.
 - c. Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.
 - d. Protective earthing is provided by Listed AC adapter. Building installation shall provide appropriate short-circuit backup protection.



Limited Warranty

ui.com/support/warranty

The limited warranty requires the use of arbitration to resolve disputes on an individual basis, and, where applicable, specify arbitration instead of jury trials or class actions.

Compliance

FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operations of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This radio transmitter has been approved by FCC.

ISED Canada

CAN ICES-3(A)/NMB-3(A)

This device complies with ISED Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This radio transmitter has been approved by ISED Canada.

The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

CAN ICES-3(A)/NMB-3(A)

Le présent appareil est conforme aux CNR d'ISDE Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. l'appareil ne doit pas produire de brouillage;
2. l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

UBB Quick Start Guide

Les dispositifs fonctionnant dans la bande 5 150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.

IMPORTANT NOTE

Radiation Exposure Statement

- This equipment complies with radiation exposure limits set forth for an uncontrolled environment.
- This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

AVIS IMPORTANT

Déclaration sur l'exposition aux rayonnements

- Cet équipement est conforme aux limites prévues pour l'exposition aux rayonnements dans un environnement non contrôlé.
- Lors de l'installation et de la mise en fonctionnement de l'équipement, assurez-vous qu'il y ait une distance minimale de 20 cm entre l'élément rayonnant et vous.
- Cet émetteur ne doit être installé à proximité d'aucune autre antenne ni d'aucun autre émetteur, et ne doit être utilisé conjointement à aucun autre de ces appareils.

Australia and New Zealand



Warning: This equipment is compliant with Class A of CISPR 32. In a residential environment this equipment may cause radio interference.

Brazil



Nota: Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados.

CE Marking

CE marking on this product represents the product is in compliance with all directives that are applicable to it.



Country List



AT	BE	BG	CY	CZ	DE	DK	EE	EL	ES	FI	FR	HR	HU
IE	IT	LV	LT	LU	MT	NL	PL	PT	RO	SE	SI	SK	UK

BFWA (Broadband Fixed Wireless Access) members noted in blue



Note: Fixed service or any restrictions for authorization of use shall follow local country regulations.

The following apply to products that operate in the 5 GHz frequency range:



Note: This device is restricted to indoor use only when operating in the 5150 - 5350 MHz frequency range within all member states.



Note: All countries listed may operate at 30 dBm. BFWA member states may operate at 36 dBm.



Note: Operation in the 5.8 GHz frequency band is prohibited in BFWA member states. Other countries listed may use the 5.8 GHz frequency band.

WEEE Compliance Statement

Online Resources

