

# VISUAL FAULT LOCATOR USER MANUAL

**Contents**

**Chapter 1 Visual Fault Locator..... 1**

**Chapter 2 Test Show..... 1**

**Chapter 3 Detailed parameter.....2**

**Product Warranty Card**

**Contact Us**

## Chapter 1 Visual Fault Locator



---


**NOTE:** Please properly install the batteries. Switch in middle for power off, switch up for CW output, switch down for glint output.

---

**CAUTION: IMPROPERLY OPERATION WILL CAUSE A DEVICE DAMAGE!  
ALWAYS MAKE SURE:**

1. Do not use inferior fibre pigtail or patch cord.
2. The connector must be well polished.
3. Always VERTICALLY insert and pull out the connector of fiber. Otherwise, the ceramic tube may be broken.

## Chapter 2 Test Show



Step 1: You can choose a continuous wave output mode for steady fault illumination or a flashing output mode by pushing the switch up and down.

Step 2: Compact and intelligent design makes it a good assistance in locating breakpoints of a fibre

### Chapter 3 Detailed parameter

Waveoutput	650nm 20nm
Fiber connector	universal-connector
Operating temp	0-+60° C
Storage temp	-20-+70° C
Battery Type	LR6 (AA) 1.5Vx2.
Battery life	>40Hrs
Dimensions	175x2.6x2.6mm
Weight	75g

## Product Warranty Card

FibreShop ensures our customers that any damage or faulty items due to our workmanship we will offer a free return within 30-Days from when you receive your goods. This excludes any custom made items or tailored solutions.

<p><b>What this warranty covers?</b></p> <p>This warranty is only available for the original buyer and is not transferable to a third-party.</p> <ul style="list-style-type: none"><li>• Within the first 30 Days of purchase, if for any reason you are not satisfied with your purchase (except custom made items or tailored solutions), simply return for a refund or replacement.</li><li>• Within the first 1 Year of purchase, free repair or maintenance due to manufacturer's defects.</li></ul>	<p><b>What is NOT covered?</b></p> <p>This warranty is non-transferable and does not cover if the product:</p> <ul style="list-style-type: none"><li>• Has been modified and/or altered, or an addition made thereto, except by FibreShop authorized representatives, or as approved by FibreShop in writing.</li><li>• Has been painted or physically modified in anyway.</li><li>• Has been subjected to misuse, abuse, negligence, abnormal or physical stress, including accident.</li><li>• Has been damaged or impaired as a result of using third party firmware.</li><li>• Has no original FibreShop label, or missing any other original labels.</li></ul>
---	---

FibreShop's sole and exclusive obligation and liability under the foregoing warranty shall be for FibreShop, at its discretion to repair or replace any product that fails to conform to the above warranty during the warranty period. The expense of removal and reinstallation of any product is not included in this warranty. The warranty period of any repaired or replaced products shall not extend beyond its original warranty expiry.

### Return Conditions

If you return for refund or replacement within **30 Days**, please make sure that the product must be in new or like-new condition with its original trademark and **SN number (the SN number is the unique identification number of every product)**, manual and accessories that were included when delivered to you. Return for replacement or repair is due to an error on our part (you received an incorrect or defective item etc. ), we will cover the shipping for the delivery of the replacement item/s only. Otherwise, you are responsible for these charges of returning or repairing items on your own. FibreShop offers two channels to process your return requests, if you purchase from online, you must visit the website from which it was purchased and log in to your "account "and complete the RA requests.