





Wave Pro















































10G





Internet





UISP Console













































































If you need further assistance, visit our Help Center or contact Ubiquiti Support.

©2023 Ubiquiti Inc. All rights reserved. Ubiquiti, the Ubiquiti U logo, UISP, and Wave are trademarks or registered trademarks of Ubiquiti Inc. in the United States and in other countries. Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries. Android, Google, Google Play, the Google Play logo are trademarks of Google LLC.